

Unical®

ALKON 09

R 18 - C 18

R 24 - C 24



INSTALLATION AND SERVICING MANUAL

Warning: this manual contains instructions to be used exclusively by the installer and/or a competent person in accordance with the current laws in force.

The end user MUST not make any alterations to the boiler.

Failure to follow the instructions indicated in this manual, which is supplied with the boiler, could cause injury to persons, animals or damage to property.

UNICAL shall not be held liable for any injury and/or damage.

CONTENTS

1	GENERAL INFORMATION	3
1.1	Symbols used in this manual	3
1.2	Correct use of the appliance	3
1.3	Water treatment	3
1.4	Information to be handed over to the user	3
1.5	Safety warnings	4
1.6	Data badge	5
1.7	General warnings	6
2	TECHNICAL FEATURES AND DIMENSIONS	7
2.1	Technical features	7
2.2	Dimensions	7
2.3	Main components	8
2.4	Boiler water circuit	9
2.5	Performance data according to the Standard UNI 10348	10
2.6	General features	10
3	INSTRUCTIONS FOR THE INSTALLER	11
3.1	General warnings	11
3.2	Standard codes for installation	12
3.3	Packaging	12
3.4	Boiler location	13
3.5	Boiler installation	15
3.6	Gas connection	15
3.7	Central heating connections	16
3.8	DHW connections	17
3.9	Examples of system pipework connections	17
3.10	Condensate drain	18
3.11	Water treatment	19
3.12	Flue outlet installation	20
3.13	Measurement on site of combustion efficiency	29
3.14	Parameters which can be modified from panel board	30
3.15	Electrical connections	31
	Connection to mains supply 230V	31
	Outdoor sensor connection	32
	ON-OFF digital room controller connection	33
	Layout of the electrical connection for zone control systems	34
3.16	Wiring diagrams	35
	Functional flow wiring diagram for Alkon 09 C	35
	Functional flow wiring diagram for Alkon 09 R	36
3.17	Filling the system	37
3.18	Initial lighting	38
3.19	Burner pressure adjustment	39
3.20	Variation of output range	41
4	SERVICING SCHEDULE	42
	Instructions for inspecting and servicing the appliance	42
5	FAULT CODES	44
6	CE CERTIFICATE	46

1

GENERAL INFORMATION

1.1 - SYMBOLS USED IN THIS MANUAL

When reading this manual particular care has to be given to the parts marked with the followings symbols:



DANGER! Indicates serious danger for your personal safety and for your life



WARNING! Indicates a potentially dangerous situation for the product and the environment



NOTE! Suggestions for the user

1.2 - A CORRECT USE OF THE APPLIANCE



The ALKON appliance has been designed utilizing today's heating technology and in compliance with the current safety regulations.

However, following an improper use, dangers could arise for the safety and life of the user or of other people, or damage could be caused to the appliance or other objects.

The appliance is designed to be used in pumped hot water central heating systems and for the production of domestic hot water.

Any other use of this appliance will be considered improper.

UNICAL declines any responsibility for any damages or injuries caused by an improper use; in this case the risk is completely at the user's responsibility.

In order to use the appliance according to the foreseen scopes it is necessary to carefully follow the instructions indicated in this manual.

1.3 - WATER TREATMENT



- The hardness of the mains water supply conditions the frequency with which the DHW heat exchanger is cleaned.
- In hard water areas where the main water can exceed 15°f total hardness, a scale reducing device is recommended. The choice of this device has to be made taking into consideration the characteristics of the water.
- In order to improve the resistance to lime scale it is recommended to adjust the domestic hot water temperature as near as possible to the one you really require.
- We recommend you to check the state of cleanliness of the domestic hot water heat exchanger at the end of the first year and subsequently, on the basis of the lime scale found, this period can be extended to two years.

1.4 - INFORMATION TO BE HANDED OVER TO THE USER



The user has to be instructed on the use and operation of his heating system, in particular:

- Hand over these instructions to the end user, together with any other literature regarding this appliance placed inside the envelope contained in the packaging. **The user has to keep these documents in a safe place in order to always have them at hand for future reference.**
- Inform the user on the importance of air vents and of the flue outlet system, stressing the fact that is absolutely forbidden to make any alterations to the boiler.
- Inform the user how to check the system's water pressure as well as informing him how to restore the correct pressure.
- Explain the function of time and temperature controls, thermostats, heating controls and radiators, to ensure the greatest possible fuel economy.
- Remind the user that, in order to comply to the standards in force, it is necessary to inspect and service the boiler according to the current codes of practice and according to the schedule indicated in this manual by the manufacturer.
- If the appliance is sold or transferred to another owner or if the present user moves home and leaves the appliance installed, ensure yourself that the manual always follows the appliance so that it can be consulted by the new owner and/or installer.

Failure to follow the instructions indicated in this guide, which is supplied with the boiler, could cause injury to persons, animals or damage to property. The manufacturer shall not be held liable for any such injury and/or damage.

1.5 - SAFETY WARNING



WARNING!

The installation, adjustment, and servicing of this appliance must be carried out by a competent person and installed in accordance with the current standards and regulations. Failure to correctly install this appliance could cause injury to persons, animals or damage to property. The manufacturer shall not be held liable for any injury and/or damage.



DANGER!

Servicing or repairs of the appliance must be carried out by UNICAL authorised service technicians; UNICAL recommends drawing up a service contract. Bad or irregular servicing could compromise the safe operation of the appliance, and could cause injury to persons, animals or damage to property for which UNICAL shall not be held liable.



Alterations to parts connected to the appliance

Do not carry out any alterations to the following parts:

- the boiler
- to the gas, air, water supply pipes and electrical supply
- to the flue pipe, safety relief valve and its drainage pipe
- to the constructive components which influence the appliance's safe operation



WARNING!

When tightening or loosening the screw pipe connections, use only adequate fork spanners.

The improper use and/or the use of inadequate equipment can cause damages (for example water or gas leakages).



WARNING!

Indications for appliances operating with propane gas

Ensure yourself that before installing the appliance the gas tank has been purged.

For a correct purging of the tank contact the liquid gas supplier or a competent person who has been legally authorized.

If the tank has not been correctly purged problems could occur during ignition.

If this occurs contact the liquid gas tank's supplier.



Smell of gas

If you smell gas follow these safety indications:

- Do not turn on or off electrical switches
- Do not smoke
- Do not use the telephone
- Close the mains gas tap
- Open all windows and doors where the gas leakage has occurred
- Contact the gas society or a company specialized in installing and servicing heating systems



Explosive and easily inflammable substances

Do not use or leave explosive or easily inflammable material (as for example: petrol, paint, paper) in the room where the appliance has been installed.

1.6 - DATA BADGE

CE Marking

- The CE marking documents that the boilers satisfy:
- The essential requirements of the Directive regarding gas appliances (Directive 90/396/CEE)

- The essential requirements of the Directive regarding electromagnetic compatibility (Directive 89/336/CEE)
- The essential requirements of the Efficiency Directive (Directive 92/42/CEE)
- The essential requirements of the low voltage Directive (Directive 73/23/CEE)





Unical®

2

Model 3	CEE 92/42 ★ 4
S.N° 5	PIN 6
Types 7	NOx 8

A 

Pn 9 kW	Pcond 10 kW
Qmax 11 kW	Adjusted Qn 12 kW
PMS 13 bar	T max 14 °C

B 

Qnw 15 kW	D 16 l/min
R factor 17	F factor 18
PMW 19 bar	T max 20 °C

C 

(21) V Hz (22) W	
IP class: (23)	

D 

(24)	(25)	(26)

E 

(27)	mbar ☐
	mbar ☐
	mbar ☐
	mbar ☐
	mbar ☐
	mbar ☐
	mbar ☐
	mbar ☐

28







LEGEND:

- | | |
|--|--|
| <p>1 = CE Surveillance notify body</p> <p>2 = Boiler type</p> <p>3 = Boiler model</p> <p>4 = Number of stars (Directive 92/42/CEE)</p> <p>5 = (S.N°) Serial number</p> <p>6 = P.I.N. code</p> <p>7 = Approved fluing configurations</p> <p>8 = (NOx) NOx class</p>
<p>A = Central Heating circuit features</p> <p>9 = (Pn) Nominal output</p> <p>10 = (Pcond) Condensing nominal output</p> <p>11 = (Qmax) Nominal heat input</p> <p>12 = (Adjusted Qn) Adjusted for nominal Heat input</p> <p>13 = (PMS) Max. pressure C.H. system</p> <p>14 = (T max) Max. C.H. temperature</p>
<p>B = Domestic Hot Water circuit features</p> <p>15 = (Qnw) Nominal heat input in D.H.W. mode (if different from Qn)</p> <p>16 = (D) Specific D.H.W. flow rate according to EN 625 - EN 13203-1</p> | <p>17 = (R factor) N° taps based on the quantity of water declared EN 13203-1</p> <p>18 = (F factor) N°stars based on the quality of water declared EN 13203-1</p> <p>19 = (PMW) Max. pressure D.H.W. system</p> <p>20 = (T max) Max. temperature D.H.W system</p>
<p>C = Electrical features</p> <p>21 = Electrical power supply</p> <p>22 = Consumption</p> <p>23 = Protection grade</p>
<p>D = Countries of destination</p> <p>24 = Direct and indirect country of destination</p> <p>25 = Gas family</p> <p>26 = Supply pressure</p>
<p>E = Factory setting</p> <p>27 = Adjusted for gas type X</p> <p>28 = Space for national brands</p> |
|--|--|

1.7 - GENERAL WARNINGS

This instruction manual is an integral and indispensable part of the product and must be retained by the user.

Please read carefully the instructions contained in this manual as they provide important indications regarding the safe installation, use and servicing of this appliance.

Keep this manual in a safe place for future reference.

The installation and servicing must be carried out in accordance with the regulations in force according to the manufacturer's instructions and by legally competent authorized persons.

By a competent person, we imply a person who has a specific technical qualification in the field of components for central heating systems for domestic use, domestic hot water production and servicing. The person must have the qualifications foreseen by the current laws in force.

Bad or irregular servicing could compromise the safe operation of the appliance, and could cause injury to persons, animals or damage to property. The manufacturer shall not be held liable for any such injury and/or damage.

Before carrying out any cleaning or servicing turn off the electrical supply to the boiler by means of the ON/OFF switch and/or by means of the appropriate shutdown devices.

Do not obstruct the inlet/outlet terminals.

In the event of failure and/or faulty functioning of the appliance, switch off the boiler. Do not attempt to make any repairs: contact qualified technicians.

Any repairs must be carried out solely by Unical authorized technicians and using only original spare parts. Non-observance of the above requirement may jeopardize the safety of the appliance.

To guarantee the efficiency and correct functioning of the appliance it is indispensable to have the boiler serviced annually by a qualified person.

If the boiler remains unused for long periods, ensure that any dangerous parts are rendered innocuous.

If the appliance is sold or transferred to another owner or if the present user moves home and leaves the appliance installed, ensure yourself that the manual always follows the appliance so that it can be consulted by the new owner and/or installer.

Only original accessories must be used for all appliances supplied with optional extras or kits (including electrical ones).

This appliance must be used only for the purposes for which it has been expressly designed. Any other use shall be considered incorrect and therefore dangerous.

2 TECHNICAL FEATURES AND DIMENSIONS

2.1 - TECHNICAL FEATURES

The **ALKON** boiler is a thermal gas fired unit with an atmospheric fully pre-mixed burner. These boilers are designed for use on the 2nd family gas category II_{2H3P}.

Range of models available:

ONLY CENTRAL HEATING PRODUCTION

ALKON 09 R 18 with an output of 18 kW;
ALKON 09 R 24 with an output of 24 kW;

CENTRAL HEATING + DOMESTIC HOT WATER PRODUCTION

ALKON 09 C 18 with an output of 18 kW;
ALKON 09 C 24 with an output of 24 kW;


The ALKON boilers are supplied complete with all the safety and control devices in accordance with all the current regulations. Their technical and functional features comply with the regulations prescribed by the law No. 1083 dated 06/12/1971, concerning safety and use of combustible gas and with the requirements prescribed in the law No. 10 dated 09/01/1991 and any subsequent amendments – Gas Directive 90/396 CEE – Efficiency Directive 92/42 CEE – Electromagnetic Compatibility Directive 89/336 CEE – Low Voltage Directive 73/23 CEE.

Moreover, the boilers of the **ALKON 09** range are classified as “CONDENSING BOILERS” according to the Directive 92/42 CEE appendix 2 (4 stars) and appendix 6 (D.M 660).

DESCRIPTION OF COMPONENTS AND FEATURES


- Aluminium heat exchanger/condenser;
- Electronic ignition;
- Flame modulation in function of the absorbed power;
- Minimum heat output adjustment in CH mode;
- Electronic adjustment of the ignition ramp;
- Electronic frost protection mode;
- Pump overrun function;
- Pump overrun function
- Safety thermostat;
- Flow temperature sensor;
- Return temperature sensor;
- DHW temperature sensor (only on the ALKON 09 C model);
- Three speed circulating pump with air vent;
- Expansion vessel;
- Automatic air vent;
- Low water pressure switch;
- Control panel with electrical protection IP X4D;
- Hydrometer
- D.H.W. temperature adjusting knob (only for model ALKON 09 “C”); position ECO(nomiser) or position FAST TEMPERATURE INCREASING SYSTEM
- CH temperature selector switch + summer/winter position;
- Push button for Reset/Calibration/Diagnostics;
- Paper wall mounting template for system pipework connections.

2.2 - DIMENSIONS




Technical features and dimensions

2.3 - MAIN COMPONENTS




- 1 Condensate drain siphon
 - 2 Aluminium heat exchanger/condenser
 - 3 Flow temperature sensor
 - 4 Overheat safety thermostat
 - 5 Ignition/Ionisation electrode
 - 6 Air vent valve
 - 7 Flue outlet/combustion air inlet
 - 8 Burner
 - 9 Fan
 - 10 Return temperature sensor
 - 11 Automatic air vent
 - 12 Pump
 - 13 System drain cock
 - 14 Central heating circuit safety valve
 - 15 Filling system cock
 - 16 Gas valve
- M C.H system flow (3/4")
 G Gas inlet (3/4")
 F Cold water inlet (1/2")
 R C.H. system return (3/4")




- 1 Condensate drain siphon
 - 2 **Domestic hot water temperature sensor**
 - 3 Aluminium heat exchanger/condenser
 - 4 Flow temperature sensor
 - 5 Overheat safety thermostat
 - 6 Ignition/Ionisation electrode
 - 7 Air vent valve
 - 8 Flue outlet/combustion air inlet
 - 9 Burner
 - 10 Fan
 - 11 Automatic air vent
 - 12 Return temperature sensor
 - 13 Pump
 - 14 System drain cock
 - 15 Central heating circuit safety valve
 - 16 Filling system cock
 - 17 Gas valve
 - 18 **Plate heat exchanger**
 - 19 **Flow switch**
 - 20 Diverter valve motor
- M C.H system flow (3/4")
 C DHW outlet (1/2")
 G Gas inlet (3/4")
 F Cold water inlet (1/2")
 R C.H. system return (3/4")

2.4 - BOILER WATER CIRCUITS

ALKON 09 "R"



ALKON 09 "C"



Technical features and dimensions

2.5 - PERFORMANCE DATA ACCORDING TO STANDARD UNI 10348

For information regarding the adjustment of: INJECTORS - BURNER PRESSURES – DIAPHRAGMS – OUTPUTS – GAS CONSUMPTIONS please refer to the paragraph BURNER PRESSURE ADJUSTMENT.

	MODEL	R 18	C 18	R 24	C 24
Max heat input	kW	18,0	18,0	23,8	23,8
Min heat input	kW	4,4	4,4	4,4	4,4
Nominal heat output 80/60	kW	17,4	17,4	23,0	23,0
Minimum heat output 80/60	kW	4,2	4,2	4,2	4,2
Efficiency at nominal load 80/60	%	96,63	96,63	96,47	96,47
Efficiency at minimal load 80/60	%	95,19	95,19	95,19	95,19
Number of stars (according to CEE 92/42)	n.	4	4	4	4
Nominal heat output in condensing mode 50/30	kW	18,4	18,4	24,0	24,0
Minimal heat output in condensing mode 50/30	kW	4,71	4,71	4,71	4,71
Efficiency at nominal load in condensing mode 50/30	%	102,08	102,08	100,92	100,92
Efficiency at minimal load in condensing mode 50/30	%	107,13	107,13	107,13	107,13
Combustion efficiency at full load (100%)	%	97,57	97,57	97,19	97,19
Combustion efficiency at reduced load	%	98,11	98,11	98,11	98,11
Losses with burner in operation	%	0,9	0,9	0,7	0,7
Losses with burner off	%	2,4	2,4	2,8	2,8
(*) Flue gas temperature $t_f - t_a$ (max)	°C	50,3	50,3	58,2	58,2
Flue gas mass flow rate (min-max)	g/s	7,89	7,89	10,43	10,43
Air excess λ	%	20,57	20,57	20,57	20,57
Condensate production max	kg/h	2,9	2,9	3,83	3,83
(**) CO ₂ (min.-max)	%	-	-	-	-
CO at 0% of O ₂ (min - max)	mg/kWh	20 - 90	20 - 90	20 - 133	20 - 133
N0x (value according to EN 297/A3 and EN 483)	mg/kWh	35,5	35,5	38,8	38,8
N0x class	%	5	5	5	5
Flue losses with burner in operation (max)	%	0,452	0,452	0,452	0,452

(*) Room Temperature = 20°C

Technical data registered with the appliance operating with natural gas (G20)

(**) See Table Injectors - Pressures

2.6 - GENERAL FEATURES

	MODELLO	18 R	18 C	24 R	24 C
Appliance's family gas category		II _{2H3P}	II _{2H3P}	II _{2H3P}	II _{2H3P}
Min. water flow rate in CH circuit (Δt 35°C)	l/min	1,7	1,31	1,7	1,7
Min. pressure in CH circuit	bar	0,5	0,5	0,5	0,5
Max. pressure in CH circuit	bar	3	3	3	3
Water content in primary circuit	l	2,2	2	2,2	2,2
Max operating temp. in CH mode	°C	85	85	85	85
Min operating temp. in CH mode	°C	30	30	30	30
Total volume CH expansion vessel	l	6	6	6	6
Total pre-loading expansion vessel	bar	1	1	1	1
Max water content CH circuit (calculated for a max temp. of 90°C)	l	111	111	111	111
Min flow rate DHW circuit	l/min	-	2	-	2
Min. DHW inlet pressure	bar	-	0,5	-	0,5
Max DHW inlet pressure	bar	-	6	-	6
DHW specific flow rate (Δt 30°C)	l/min.	-	8,8	-	11,2
DHW flow restrictor	l/min.	-	12	-	12
DHW production in continuous operation with Δt 45 K	l/min.	-	5,7	-	7,34
DHW production in continuous operation with Δt 40 K	l/min.	-	6,4	-	8,26
DHW production in continuous operation with Δt 35 K	l/min.	-	7,3	-	9,44
DHW production in continuous operation with Δt 30 K (°)	l/min.	-	8,6	-	11,0
DHW production in continuous operation with Δt 25 K (°)	l/min.	-	10,3	-	13,2
DHW adjustable temperature	°C	-	38-60	-	38-60
Electrical supply /power consumption	V-Hz	230/50	230/50	230/50	230/50
Fuse rating	A (F)	4	4	4	4
Maximum absorbed power	W	120	120	132	132
Electrical protection	IP	X4D	X4D	X4D	X4D
Net weight	kg	33	36	33	36

(*) mixed

3

INSTRUCTIONS FOR THE INSTALLER

3.1 - GENERAL WARNINGS



WARNING!

This boiler has to be destined for the use for which it has been expressly designed for. Any other use shall be considered improper and therefore dangerous.

This boiler is designed to heat water at a temperature inferior to boiling point at an atmospheric pressure.



WARNING!

These appliances are exclusively designed to be installed inside adequate sitings. Therefore these appliances must not be installed and operated outdoors. An outdoor installation could cause malfunctioning and could be dangerous. For external installations, it is recommended to use appliances which are specifically designed and predisposed for this purpose.



Before installing the boiler the following points have to be carried out by a competent engineer:

- a) The whole system should be thoroughly flushed in order to remove any residual dirt or grime which could compromise correct boiler operation.
- b) Check that the boiler has been preset for operating with the gas type available. This is verifiable via the indication on the packaging and on the data badge;
- c) Check that the chimney/flue pipe has an adequate draught, does not have any constrictions, and that no other appliance's flue outlets have been fitted, unless the chimney is serving more than one heating appliance, according to the specific standards and regulations in force. The connection between the boiler and chimney/flue outlet can be made only after this verification has been carried out.



WARNING!

In rooms where aggressive vapours or dust is present the appliance must operate independently from the air present in the boiler's location room!



WARNING!

The appliance must be installed by a qualified engineer, who complies to the technical-professional requirements according to the law 46/90 and whom, under his own responsibility, guarantees the compliance of the standards according to the latest regulations.



WARNING!

The appliance must be installed only on a vertical flat wall, made of non combustible material.

The appliance must be positioned so that at least the minimum operational and servicing clearances are provided.



NOTE:

The boiler must be connected to a heating system which is compatible to its performance and output.

Instruction for the installer

3.2 – STANDARD CODES FOR INSTALLATION

The **ALKON** boiler is a thermal unit designed for use with the family gas category II_{2H3P}.

The appliance must be installed in compliance to the instructions contained in this manual.

The installation must be carried out by a competent qualified engineer, **whom will assume the responsibility of complying to all the local and/or national regulations published in the official publications, as well as all the applicable codes of practice.**

The installation must be carried in accordance to the codes of practice, the regulations and the requirements hereby indicated, which constitute an indicative list, but not a complete one, as these continue to undergo developments.

National installation regulations:

Gas plants for domestic use fed by network distribution
Standard UNI-CIG 7129

Gas plants for domestic use not fed by network distribution
Standard UNI-CIG 7131

Law dated 5.03.90 n°46

Law dated 9.01.91 n°10

Other applicable statutory requirements:

Law 1083/71 (ref. Standard UNI for the design, installation and maintenance).

Law 46/90 and D.P.R. 447/91

Law 10/91 and D.P.R. 412/93 and subsequent amendments

D.M 1.12.1975

Moreover, the boiler must be installed in accordance to all the regulations regarding the boiler room, and comply to the building regulations and the prescriptions regarding central heating plants in force in the country the boiler is installed.

The appliance must be installed, commissioned and serviced according to the regulations in force. This is also valid for the hydraulic system, the flue outlet system and the boiler location room.

3.3 - PACKAGING

The **ALKON** 09 range of boilers are supplied fully assembled in a strong cardboard box.



Note:

DO NOT DISPOSE OF PACKAGING IN THE ENVIRONMENT



After having unpacked the boiler check that it is intact and undamaged.




Keep the packaging material (cardboard box, plastic bags, polyester protection etc.) **out of the reach of children as they can be dangerous.**

UNICAL refuses all liability for injury to persons, animals or damage to property deriving from not having respected the above mentioned recommendations.

In the packaging, in addition to the boiler, you can also find the following contents:

- Service logbook
- User's instruction guide
- This installation and servicing manual
- Warranty
- Nr. 2 spare parts request coupons
- N° 2 wall plugs for fixing the boiler to the wall
- Pipe kit
- Wall mounting template
- Rubber spacer for two pipe evacuation systems



3.4 - BOILER LOCATION

When selecting the position for the installation of the boiler please comply to the following safety requirements:

- Fit the appliance in rooms protected from frost;
- In rooms where aggressive vapours or dust are present, the appliance must be able to operate independently from the air of the location room;
- The appliance must be installed exclusively on a vertical and solid wall, capable of adequately supporting the weight of the boiler;
- The wall must not be made of inflammable material;
- Leave on each side of the appliance a sufficient clearance in order to allow easy service works.


Every appliance is supplied with a paper "Wall mounting template" which facilitates the connection of the gas and water feed pipes when laying out the hydraulic system and before installing the boiler.

This template has to be fixed on to the wall chosen for the installation.

The upper part gives the indications to drill on the wall the fixing holes for the boiler supporting bracket and for the rear smoke outlet.

The lower part of the template marks the correct positioning of the system pipework connections for the following parts:


M = CH system flow (3/4")
C = Hot water outlet (1/2")
G = Gas supply (3/4")
F = Cold water supply (1/2")
R = CH system return (3/4")



VIEW FROM BELOW


LOWER VUE OF CONNECTIONS

- Filling valve (**Rc**)
- Safety valve discharge (**Vs**)
- Condensate evacuation (**Sc**)
- C.H. system drain (**Si**)




Instruction for the installer

Dimensions of diverting valve kit for ALKON 09 R for external D.H.W. tank connection



Dimensions for the connection of ALKON 09 R to the external D.H.W. tank DSP 110



3.5 - BOILER INSTALLATION

Before connecting the boiler to the heating system the following requirements must be carried out by competent and qualified engineers:

- a) The system is flushed out with a suitable product in order to eliminate any metallic tooling or welding residues and oil and grime which could reach the boiler and affect the proper running of the boiler;
- b) Check that the boiler has been preset for operating with the gas type available.
This is verifiable via the indication on the packaging and on the data badge;
- c) Check that the chimney/flue pipe has an adequate draught, does not have any constrictions, and that no other appliance's flue outlets have been fitted, unless the chimney is serving more than one heating appliance, according to the specific standards and regulations in force. The connection between the boiler and chimney/flue outlet can be made only after this verification has been carried out.

For fitting the boiler:

- Place the steel mounting template on to the wall.
- Determine the position of the holes for fixing the support bracket.
- Drill the holes and fix the support bracket using the fixing screws as indicated on page 13.
- Engage the boiler on to the support bracket.
- Mark the positions of the gas, cold water supply, hot water outlet, CH flow and return, pressure relief valve and/or condensate drain.



Note: The appliances are equipped with expansion vessels. Before installing the appliance check that the vessel's capacity is sufficient; if this is not the case, provision must be made to fit an additional expansion vessel.

3.6 - GAS CONNECTION



DANGER!

The gas connection must be carried out only by a qualified engineer who will have to respect and comply to the regulations in force and to the requirements indicated by the local gas supplier. An incorrect installation could cause injury to persons, animals or damage to property. The manufacturer shall not be held liable for any injury and/or damage.



Before installing the boiler it is recommended to thoroughly clean all the fuel feed pipework in order to remove any eventual residual grime which could compromise the boilers correct functioning.



If you smell gas:

- a. Do not turn on or off electrical switches, use the telephone or any other object which can provoke sparks;
- b. Open all doors and windows in order to allow fresh air to enter and purify the room;
- c. Close all gas cocks;
- d. Contact a service engineer, qualified installer or the gas supply company.



As a safety measure against gas leaks, Unical recommends installing a surveillance and protective system composed of a gas leakage detector combined with an on-off selenoid valve fitted on the gas supply line.

The gas supply pipe must have a section which is identical or greater than the one used on the boiler and must assure a correct gas pressure.

It is however important to comply with the "General installation standards" indicated in the standards UNI 7129, UNI 7131 and UNI 1137-1.

Before commissioning an internal gas distribution system and therefore before connecting it to the gas meter, the complete installation must be tested for gas soundness.

If any part of the system is concealed from view the gas soundness test must be carried out before covering the pipes.

Before connecting the pipework the system must be tested with air or inert gas at a pressure of at least 100mbar.

Before commissioning the boiler ensure that the following operations are carried out:

- Open the gas meter cock and vent the air contained in the piping and subsequently proceed to vent device by device.
- Check, with the gas cock turned off, that there are no gas leaks. During the 2nd quarter of the hour from the start of the test, no pressure reduction should be detected by the pressure gauge. Any gas leaks must be found by using only water soap solutions, or an equivalent product, and eliminated. **Never look for gas leaks using a naked flame.**

3.7 - CENTRAL HEATING CONNECTIONS



WARNING!

Before installing the boiler we recommend that the system is flushed out with a suitable product in order to eliminate any metallic tooling or welding residues, oil and grime which could reach the boiler and affect the proper running of the boiler.

Do not use any solvents for flushing out the system as they could damage the system and/or its components.

Non-observance of these instructions could cause injury to persons, animals or damage to property. The manufacturer shall not be held liable for any such injury and/or damage.

The CH flow and return circuits have to be connected to the boiler via the respective connections $\frac{3}{4}$ " M and R as indicated on page 13.

When determining the size of the CH circuit pipes it is essential to bear in mind the pressure losses induced by the radiators, any eventual thermostatic radiator valves, lockshield valves and by the system's layout.

The routing of the piping has to be laid down taking all the necessary precautions in order to avoid air locks and to facilitate the continuous purging of the system.



Ensure yourself that the system's piping is not used as earth clamps for the electrical or telephonic system. They are absolutely unsuitable for this use. In a short time this could cause serious damage to the piping, boiler and radiators.

The boiler is fitted with an automatic BY-PASS (differential valve with a flow rate of about 150 l/h) which always ensures a minimum water flow rate to the heat exchanger even if, for example, all the thermostatic valves fitted on the heating system are closed.

Pressure relief valve drain pipe

In correspondence to the heating pressure relief valve provision should be made to install a discharge pipe with a funnel and a siphon which lead to an adequate drainage. The drainage has to be controllable by sight.




WARNING!

If this precaution is not taken it could lead to injury to persons, animals or damage to property.

The manufacturer shall not be held liable for any such injury and/or damage.

BOILER CIRCULATION PUMP

Graph – Water flow rate/ available head for installation– ALKON 24 kW



3.8 - DOMESTIC HOT WATER CONNECTIONS (Model "C")



WARNING!

Before connecting the boiler to the water mains supply ensure that the system is flushed out with a suitable product in order to eliminate any metallic tooling or welding residues, oil and grime which could reach the boiler and affect the proper running of the boiler.

Non-observance of these instructions could cause injury to persons, animals or damage to property. The manufacturer shall not be held liable for any such injury and/or damage.

The hot water distribution and domestic hot water supply pipework must be connected to their respective ½ boiler pipe connections C and F as indicated on page 13.



The pressure in the system must be between 1 and 3 bar (if the pressure is higher fit a reducing pressure valve).



WARNING!

The hardness of the mains water supply conditions the frequency with which the DHW heat exchanger is cleaned.

In hard water areas the opportunity of fitting an adequate scale reducing device for domestic purposes for treating the mains water supply to the boiler, in compliance to the DM n°443 dated 21/12/90, should be taken into consideration.

Where water hardness exceeds 15°f, a scale reducing device is always recommended.




Ensure yourself that the system's water and central heating piping are not used as earth clamps for the electrical or telephonic system. They are absolutely unsuitable for this use. In a short time this could cause serious damage to the piping, boiler and radiators.

3.9 - EXAMPLES OF SYSTEM PIPEWORK CONNECTIONS


CONNECTION WITH STRAIGHT PIPES

00361193 Straight pipework kit (supplied with the boiler)




CONNECTION WITH STRAIGHT PIPES + BICONIC NIPPLES

00361265 Straight pipework kit with biconic nipples



CONNECTION WITH STRAIGHT PIPES + ON-OFF VALVES

00360682 On-Off valves (optional extra) + 00361193 Straight pipework kit (supplied with the boiler)



3.10 - CONDENSATE DRAIN

During the combustion process the boiler produces condensate which, through the "A" pipe, flows into the siphon. The condensate which forms inside the boiler has to be routed into an adequate drain by means of the pipe "B".




DANGER!

Before commissioning the appliance fill the siphon and check the correct drainage of the condensate.

If the appliance is used with the condensate drain siphon empty there could be danger of intoxication resulting from the escape of flue gasses.

The connection between the appliance and the sewage system must be carried out in compliance with the specific reference standards, and in particular:

- prevent the end user utilizing the condensate produced;
- a siphon must be fitted (supplied with the boiler);
- there must be no bottlenecks;
- the connection must be made just under the bottom part of the boiler;
- it must be installed so as to avoid freezing of the liquid when the boiler is operating and prevent the eventual pressurization of the sewage system;
- consent the correct downflow of the appliance's liquid discharges;
- it must be made with one of the following materials which are resistant to condensate:
 - Grès, according to the Standards DIN 1230-1 and 6, EN 295-1 or 2 or 3;
 - Glass (boron silicate);
 - Polyvinyl chloride (PVC), according to DIN V 19534-1 and 2, and DIN 19538;
 - Polyethylene (PE) DH type, according to DIN 19535-1 and 2 and DIN 19537-1 and 2;
 - Polypropylene (PP) and copolymer styrene (ABS) according to DIN V 19561;
 - Polyesterific resin (GF-UP), according to DIN 19565-1;
 - Stainless steel.



3.11 - WATER TREATMENT

The chemical/physical features of the heating system's water are fundamental for the boiler's correct operation and safety.

Among the inconvenients caused by the bad quality of the feeding water, the most frequent and the most serious is the incrustation of the boiler thermal exchange surfaces.

Less frequent, but also serious, is the hydraulic circuit surfaces.

It is ascertained that the boiler incrustations, due to their low thermal conductivity, highly reduce the thermal exchange, even if with a thickness of some millimetres and provoke a very dangerous localised overheating.

We suggest to make the water treatment of the heating circuit in the following cases:

- a) When the hardness of the water is higher than 15°f;
- b) For C.H. installations with large water content;
- c) Renewal of the water system due to uncontrolled leakages;
- d) Subsequent refilling of the system due to maintenance works on the installation;
- e) Presence of different metals in the hydraulic circuit.

The scope of this treatment is finalized for eliminating or substantially reducing the following problems:

- lime scale deposit
- corrosion sludge
- deposits
- microbiological growths (moulds, bacteria etc.)

An appropriate treatment of the supply water will prevent the above stated problems and will maintain the correct operation and efficiency of the generator in time.

For this purpose it will be necessary to fix the following chemical-physical characteristics of the water:



PH include between 6,5 and 8
Hardness 15° FR

Therefore, before filling the heating system it will be necessary to fit the devices indicated in the figure.

THE INSTALLATION MUST BE FORESEEN ON THE RETURN PIPE OF THE PRIMARY CIRCUIT DOWNSTREAM OF THE CIRCULATING PUMP.

All necessary precautions must be taken for preventing the formation and localization of oxygen in the system's water. For this reason, ensure yourself that the plastic piping used in underfloor heating systems is impermeable to oxygen.

If any anti-freeze solutions are used ensure that they are compatible with aluminium and any other boiler components and materials.



WARNING!

Any damage caused to the boiler due to the formation of lime scale or by corrosive water will not be covered by the warranty.

Instruction for the installer

3.12 - FLUE OUTLET INSTALLATION

The flue system must be installed in accordance with the local and national Standards (refer to Standard UNI-CIG 7129, point 4 and UNI-CIG point 5)




We recommend using only original UNICAL flue outlet systems. Damages caused by installation errors and for non-observance of the instructions given by the same manufacturer will invalidate all the supplier's contractual or extra contractual responsibilities.


If the boiler has to be replaced **ALWAYS** replace the flue outlet system.

The boiler has been approved for the following flue configurations:


- C13** Boiler designed for connection to horizontal inlet and outlet terminals, which admit fresh air to the burner and discharge the products of combustion to the outside through concentric or twin ducts. The minimum distance between the inlet air duct and the flue outlet duct must be of 250 mm and both terminals must be positioned within a 500 mm square section.




- C33** Boiler designed for connection to vertical inlet and outlet terminals, which admit fresh air to the burner and discharge the products of combustion to the outside through concentric or twin ducts. The minimum distance between the air inlet duct and the flue gas outlet duct must be of 250 mm and moreover both terminals must be positioned within a 500 mm square area.



- C43** Boiler designed for connection to collective flue systems including two ducts, one for the air inlet and the other for the discharge of products of combustion through concentric or twin ducts.




- C53** Boiler with separate air inlet and products outlet. These ducts can discharge into areas with different pressure. **The two terminals must not be fitted on to two opposite walls.**




Type C63

Boiler designed for connection to a combustion air inlet and flue products discharge system approved and sold separately.




- C83** Boiler designed for connection to a terminal for the intake of combustion air and to an individual or collective chimney for the discharge of the products of combustion. **The chimney must comply to the current regulations.**



- B23** Boiler designed to be connected to an open flue which will terminate vertically through the roof. The combustion air is withdrawn directly from the room where the boiler is installed.

WARNING: for this type of connection the room must comply with the same installation regulations valid for open chimney boilers.

The chimney must comply to the current regulations.




SMOKE EVACUATION Ø80 mm with AIR INTAKE FLANGE - Installation type B23

The maximum allowed virtual length for the smoke evacuation duct is 20 m, included one wide radius curve and one evacuation terminal.



For this type of installation the smoke evacuation duct has to be independent.



WARNING: The combustion air is taken from the room where the boiler is installed. If the boiler is installed in an unventilated room, convenient ventilation openings need to be done.

For installations where there is the freezing risk, it is suggested to insulate the smoke evacuation duct Ø80 mm in all its length, even if its layout is within a chimney.



Fit the rubber spacer, supplied with the boiler, as shown in the picture.


Instruction for the installer

HORIZONTAL FLUE OUTLET WITH CONCENTRIC DUCTS Ø 60/100 mm



Type C13

The minimum allowable length of the horizontal concentric pipes is of 0,75 metres.

The maximum allowable length of the horizontal concentric pipes is of 3,5 metres. For each elbow added the maximum length permitted has to be reduced by 1 metre.



Important: the outlet/inlet flue has to have a minimum inclination of 3% towards the top in the outlet direction, so as to enable the collection of any condensate formed in the boiler.




Type C33

The maximum allowable length of the vertical concentric pipes is of 8,5 metres, apart from the terminal Ø 80/125. For each elbow added the maximum length permitted has to be reduced by 1 metre.



Fit the rubber spacer, supplied with the boiler, as shown in the picture.




HORIZONTAL FLUE OUTLET WITH CONCENTRIC DUCTS Ø 80/125 mm



Type C13

The minimum allowable length of the horizontal concentric pipes is of 0,75 metres.

The maximum allowable length of the horizontal concentric pipes is of 6 metres. For each elbow added the maximum length permitted has to be reduced by 1 metre. Moreover, the flue outlet has to have a minimum inclination of 3% towards the top in the outlet direction, so as to enable the collection of any condensate formed in the boiler.



Important: the outlet/inlet flue has to have a minimum inclination of 3% towards the top in the outlet direction, so as to enable the collection of any condensate formed in the boiler.




Type C33

The maximum allowable length of the vertical concentric pipes is of 8,5 metres, including the terminal Ø 80/125. For each elbow added the maximum length permitted has to be reduced by 1 metre.





Fit the rubber spacer, supplied with the boiler, as shown in the picture.



Instruction for the installer

FLUE OUTLET WITH SEPARATE DUCTS Ø 80 mm



Fit the rubber spacer, supplied with the boiler, as shown in the picture.



It is not permitted to position the two terminals on opposite walls.

FLUE OUTLET WITH SEPARATE DUCTS Ø 80 mm Type C53 (Only for inside installations)

The maximum allowable length of the horizontal separate pipes Ø 80 is of **58 metres**.



For rectilinear length it is intended without curves and suction/ evacuation terminals.

For the calculation related to the configurations, (example 1 or 2) it is necessary to deduct, from the maximum allowed length, the resistance in meters related to the different accessories (see table).


Table of the flue losses for smoke accessories Ø 80 mm

For each one of them deduct, from the maximum allowed Length, the corresponding flue losses in meters.

- curve with narrow radius Ø 80	=	9 m
- curve with wide radius Ø 80	=	2,5 m
- horizontal suction terminal Ø 80	=	2,3 m
- horizontal evacuation terminal Ø 80	=	3,5 m
- vertical evacuation duct Ø 80	=	5,3 m




It is not permitted to position the two terminals on opposite walls.



$$L \text{ max} = L1 + L2 = 58 \text{ m}$$

$$L \text{ max} = L1 + L2 = \begin{array}{r} 58,0 \text{ m} - \\ 2 \text{ curve with wide radius } 5,0 \text{ m} - \\ \hline 53,0 \text{ m} \end{array}$$



Instruction for the installer


Example N.1

Intake of primary air from the perimeter wall and flue discharge from the roof.

L max =	58,0 m -
1 Curve with wide radius	2,5 m -
1 horizontal suction terminal	2,3 m -
1 Vertical evacuation duct	<u>5,3 m =</u>
	47,9 m




With this configuration there are still 47,9 m available to be shared between the suction and evacuation ducts.



Example N.2

Intake of primary air and flue discharge from two external perimeter walls.



L max =	58,0 m -
2 curve with wide radius	5,0 m -
1 horizontal suction terminal	2,3 m -
1 horizontal evacuation terminal	<u>3,5 m =</u>
	47,2 m



With this configuration there are still 47,2 m available to be shared between the suction and evacuation ducts.



It is not permitted to position the two terminals on opposite walls.

FLUE CONFIGURATION Ø 60 mm

The maximum allowable length of the horizontal separate pipes Ø 60 is of **20 metres**.



For rectilinear length it is intended without curves and suction/ evacuation terminals.

or the calculation related to the configurations, (example 1 or 2) it is necessary to deduct, from the maximum allowed length, the resistance in meters related to the different accessories (see table).

Table of the flue losses for smoke accessories Ø 60 mm


For each one of them deduct, from the maximum allowed Length, the corresponding flue losses in meters.

- curve with wide radius Ø 60	=	0,8 m
- horizontal suction terminal Ø 60	=	1,2 m
- horizontal evacuation terminal Ø 60	=	2,0 m
- vertical evacuation duct Ø 80 + red. Ø 60	=	2,8 m




Note:

These values refer to flue systems mounted with original UNICAL non flexible and smooth pipes.



$$L \text{ max} = L1 + L2 = 20 \text{ m}$$



Instruction for the installer


Example N.1

Intake of primary air from the perimeter wall and flue discharge from the roof.

L max =	20,0 m -
1 Curve with wide radius	0,8 m -
1 horizontal suction terminal	1,2 m -
1 Vertical evacuation duct	2,8 m =
	15,2 m



With this configuration there are still 15,2 m available to be shared between the suction and evacuation ducts.




Example N.2

Intake of primary air and flue discharge from two external perimeter walls.



It is not permitted to position the two terminals on opposite walls.



L max =	20,0 m -
2 Curve with wide radius	1,6 m -
1 horizontal suction terminal	1,2 m -
1 horizontal evacuation terminal	2,0 m =
	15,2 m



With this configuration there are still 15,2 m available to be shared between the suction and evacuation ducts.




UNICAL is not responsible for any damage caused as result of mistakes in the installation, utilization or transformation or for no compliance with the instructions supplied by the manufacturer or with the installation codes in force in the destination country.

3.13- MEASUREMENT ON SITE OF COMBUSTION EFFICIENCY

To determine the combustion efficiency it is necessary to measure:

- The combustion air temperature in the measuring point **2**.
- The smoke temperature and the CO₂ value in the measuring point **1**.

Take the indicated measurements with the boiler in steady state, using the special function push button.



Instruction for the installer

3.14 - PARAMETERS WHICH CAN BE MODIFIED FROM PANEL BOARD



WARNING!

Function reserved exclusively to the Authorized Service Centres!


Some of the service parameters can be modified from the panel board:

- PUMP OVERRUN

0 = 5 min

1 = Continuous operation

Factory setting: 0



x 10"





To enter the parameters push and keep pressed for ten seconds the reset button (release when the flashing wrench appears  on the display).

- OUTER SENSOR TEMPERATURE ADJUSTMENT

Possible setting from 0 (-20°C) to 30 (+10°C)

Factory setting: 20 (0°C)




Rotate the HEATING temperature adjustment knob "B" to select the parameter which needs to be changed: Po - °C - nr - PH - HP; the parameters are shown on the display "E".

- NIGHT REDUCTION

Desired value 0 (DISABLED)

Possible setting from 0°C to 30°C (ENABLED)

Factory setting: 0





Confirm the parameter to be changed by pressing the reset button.

- ENABLING/DISABLING ECO / COMFORT

0 = OFF 1 = ON

Factory setting: 1




Modify the value of the parameter previously selected by rotating the D.H.W. temperature adjustment knob "C". The new value flashes on the display.

- MAXIMUM HEATING OUTPUT ADJUSTMENT

Possible setting from 0 to 99



Factory setting: 99



Modify the value of the parameter previously selected by rotating the D.H.W. temperature adjustment knob "C". The new value flashes on the display.

Store the new value of the parameter by pushing the reset button.

To exit from parameter list wait 20 s or rotate quickly the D.H.W. temperature adjustment knob "C".




Reset button with calibration function



WARNING!
Function reserved exclusively to the Authorized Service Centres!

Operation at the maximum output

Rotate the HEATING temperature adjustment knob "B" to its maximum setting and subsequently push the reset button for 3 s. (release when the steady wrench appears on the display).



3 sec.



maximum setting and subsequently push the reset button for 3 s. (release when the steady wrench appears on the display).


The symbols (M) and (F) are ON. The boiler is forced in operation at its maximum output so that the calibration operations and the combustion analysis can be performed.



Maximum output:
(symbol wrench = steady and symbol radiator = steady)

Operation at the minimum output

Rotate the HEATING temperature adjustment knob "B" between the sun and its minimum setting: the boiler operates at minimum output.



Minimum output:
(symbol wrench = steady and symbol radiator = flashing)

The function *calibration* remains active for 15 s. To deactivate the function **CALIBRATION** before 15 s are elapsed, push again the reset button for 3 s.



Warning:
If the reset button "D" is kept depressed for more than 6 s the symbol wrench disappears and, when released, it is not possible to enter the special function mode.

3.15 - ELECTRICAL CONNECTIONS

The appliance's electrical safety is guaranteed only when the same appliance has been correctly earthed in compliance with the regulations in force. The gas and water feeding pipes and the CH system pipes cannot be used as ground plates.

Ensure that the above safety electrical requirements subsist; in case of doubt, ask for a professionally qualified technician to check the appliance's electrical system.

UNICAL refuses responsibility for any damages arising from failure to earth the boiler correctly.

It is necessary that a qualified technician verifies that the electrical system is adequate to the appliance's maximum absorbed power, indicated on the data plate, verifying in particular that the section of the system's cables is suitable to the appliance's maximum absorbed power.

For the appliance's general electrical supply the use of adaptors, multiple sockets and/or extension cords is strictly forbidden.

The use of any power supplied equipment implies the observance of several fundamental rules, such as:

- Do not touch the appliance with any wet part of your body and/or barefooted;
- Do not pull the supply cables;
- Do not expose the boiler to sunlight, rain, etc., unless it is explicitly foreseen;
- Do not permit children or inexperienced people to use the appliance.

Connection to mains supply 230V



The boiler is provided complete with a 1,5 m long, mains supply cable, with a cross section area of 3x0,75 mm².

The boiler's electrical connections are shown in the section named "WIRING DIAGRAMS" (paragraph 3.14 pages 37)

A mains supply of 230 V – 50 Hz is required. The wiring to the boiler must be in accordance with the current CEI regulations.



DANGER!
The electrical connections must be carried out only by a qualified engineer.
Before carrying out the connections or any other operation on the electrical parts, always switch off and disconnect the electricity supply and ensure yourself that it cannot be accidentally turned on.



Note: It is necessary to fit a double pole switch on the electrical supply line, having a 3 mm contact separation in both poles, in an easy accessible position so as to ensure quick and safe servicing.

The replacement of the supply cable as to be carried out by a qualified authorized UNICAL engineer, using only original spare parts. The non-observance of the above could compromise the appliance's safety.

Instruction for the installer

Outdoor sensor connection (optional)


- The connection of the outer sensor has to be made on the terminals 5 & 6 of the terminal strip M1.



With this solution it is possible to control the flow temperature according to the variations of the outdoor temperature. However, it is necessary to configure the heating curve. The curve can be "drawn" by setting the maximum and minimum flow design temperatures: the first one must be selected on the boiler (via the "C" knob on the control panel – max. setting 85°C), whilst the second is set at 30°C (MINIMUM HEATING TEMPERATURE).

Subsequently we have to make the maximum flow temperature correspond to the minimum external temperature by setting the Otc parameter (outdoor sensor set-point)

CH Setpoint vs ExtSensor



This adjustment must be made via the knob positioned on the rear side of the panel (turn the knob in an anti-clockwise direction between a value from 10 to -19). Obviously this temperature is different from zone to zone and varies in function of the climatic conditions of the installation site (it corresponds to the minimum design temperature). The minimum flow temperature instead (HL) is automatically set by the boiler when the outdoor temperature is +20°C. Once these parameters have been set the boiler will choose a flow temperature on the heating curve on the basis of the outdoor sensor readout.



Note:

This adjustment could be susceptible to subsequent slight changes in function of the outdoor sensor's location.






The temperature detected by the outer sensor is sent also to the REGOLAFACILE (if there) and elaborated by the REGOLAFACILE it self according to the setting of the heating curve. In case of contemporary heat request by the ON-OFF zone and the zone controlled by the REGOLAFACILE, the ON-OFF zone has the priority.

ON-OFF digital room controller connection (optional)



DANGER!
Switch off and disconnect the electricity supply before carrying out any operations on the electrical parts.

- Get access to the terminal strip M1
- Remove the shunt 1-2 and connect at its place the leads coming from room thermostat TA.



Modulating RT/OT digital room controller connection (optional)






WARNING!
The modulating room controllers must be supplied by Unical.




DANGER!
Switch off and disconnect the electricity supply before carrying out any operations on the electrical parts.

- Get access to the terminal strip M1
- Connect the leads coming from REGOLAFACILE to the terminals 3-4 of terminal strip M1.
- Remove the link between terminals 1-2.





Instruction for the installer

Layout of the electrical connections for zone control systems



When the thermostat's contact (On-Off) is closed, the 3-way valve opens the high temperature zone and closes the low temperature zone (controlled by the digital room controller "Regolafacile").

With the thermostat's contact (On-Off) open, the 3-way valve deviates towards the low temperature zone (the temperature value can be adjusted with the digital room controller).




The microswitch on the 3-way valve closes whilst the room thermostat is demanding heat when the diverter valve reaches the "low temperature" position and sends the request to the boiler.


The 3-way valve has to use the limit switch contact in order to simulate this type of request.

3.16 - WIRING DIAGRAMS

FUNCTIONAL FLOW WIRING DIAGRAM ALKON 09 R 18 - R 24




Note:
The figures shown on the above wiring diagram are purely indicative



- | | | |
|--------------|---|---|
| A7...A18 | = | Connectors |
| DK | = | Safety pressure switch against lack of water |
| E. ACC./RIL. | = | Combined ignition/ionisation electrode |
| FL | = | Minimum flow switch |
| MVD | = | Motor of Diverting Valve (optional) |
| P | = | Circulating pump |
| SR | = | Heating flow temperature sensor |
| SRR | = | Heating return temperature sensor |
| SS | = | D.H.W. temperature sensor (for external storage tank) |
| TL | = | Limit thermostat |
| VG | = | Gas valve |
| VM | = | Modulating fan |
| SE | = | Terminals for outer temperature sensor |
| OT | = | Terminals for Modulating Room Thermostat (REGOLAFACILE) |
| TA | = | Terminals for ON-OFF Room Thermostat |


Instruction for the installer

FUNCTIONAL FLOW WIRING DIAGRAM ALKON 09 C 18 - C 24




Note:

The figures shown on the above wiring diagram are purely indicative



- | | | |
|--------------|---|---|
| A7...A18 | = | Connectors |
| DK | = | Safety pressure switch against lack of water |
| E. ACC./RIL. | = | Combined ignition/ionisation electrode |
| FL | = | Minimum flow switch |
| MVD | = | Motor of Diverting Valve |
| P | = | Circulating pump |
| SR | = | Heating flow temperature sensor |
| SRR | = | Heating return temperature sensor |
| SS | = | D.H.W. temperature sensor |
| TL | = | Limit thermostat |
| VG | = | Gas valve |
| VM | = | Modulating fan |
| SE | = | Terminals for outer temperature sensor |
| OT | = | Terminals for Modulating Room Thermostat (REGOLAFACILE) |
| TA | = | Terminals for ON-OFF Room Thermostat |



FASTON ANTI-WITHDRAWING

If necessary the faston can be removed by slightly bending the safety tab "A" with a very small screw driver.

3.17 - FILLING THE SYSTEM

Warning!

Do not mix the CH system's water with unsuitable anti-freeze products (example: anti-freeze solutions for motor vehicles) or use wrong concentrations of anti-corrosion solutions ! This could cause damage to the washers and could provoke noise during normal boiler operation. If really necessary, use exclusively specific anti-freeze products suitable for use on aluminium-silicon alloy. UNICAL refuses all liability for injury to persons, animals or damage to property deriving from not having respected the above mentioned recommendations.

After completing all the system's service connections the circuits may be filled by carefully following out the following phases:

- open the radiator's air vents and check that the automatic air vent in the boiler is working properly.
- gradually open the appropriate filling cock and check that the automatic air vents fitted onto the system are working properly.

FILLING
COCK



- close the radiator's air vents as soon as water begins to flow out.
- using the pressure gauge check that the pressure reaches the value of 0,8/1 bar.
- close the filling cock and then bleed off the air once again through the radiator's air vents.
- check all the connections for soundness.
- after having fired the boiler and the system has reached the correct temperature, stop the pump and repeat the air bleeding operations.
- let the system cool down and, if necessary, re-establish the water pressure to 0,8/1 bar.



NOTE:

The minimum low water pressure switch will not give the electrical impulse to fire the burner if the pressure is lower than 0,4 bar.

The pressure of the water in the CH system must not be lower than 0,8/1 bar; if this value is lower use the filling cock on the boiler to adjust the pressure.

This operation must be carried out when the system is cold. Use the pressure gauge fitted on the boiler to read the circuit's pressure value.



NOTE!

If the boiler has not been fired for a long period the pump could be jammed. Before firing the boiler, it is important to carry out the following un-jamming operation:

- place a cloth underneath the pump
- remove the pump vent plug positioned in the centre of the pump
- using a screwdriver, rotate the shaft in a clockwise direction.

Once this operation has been concluded, screw back the pump vent plug and check that there have been no water leaks.



WARNING!

After removing the pump vent plug some slight water leakage could occur. Before replacing the front panel dry all the wet surfaces.

3.18 - INITIAL LIGHTING

PRELIMINARY CHECKS



The first ignition must be carried out by a qualified technician. Failure to do so could cause injury to persons, animals or damage to property. UNICAL shall not be held liable for any injury and/or damage.

Before lighting the boiler check that:

- the boiler installation has been carried out in accordance with the specific Standards UNI 7129 and 7131 for the gas part and the Standards CEI 64-8 and 64-9 for the electrical part;
- the combustion air inlet and the discharge of the products of combustion occur in the correct way in accordance to the specific Standards in force (UNI 7129/7131);
- the gas supply system is correctly dimensioned for the boiler's output;
- the boiler's electrical supply is 230 V - 50 Hz;
- the system has been filled with water (pressure registered on the gauge 0,8/1 bar with pump not running);
- any of the system's on-off valves are open;
- the mains supply gas corresponds to the one which the boiler has been calibrated for: otherwise convert the boiler to use the available gas (refer to section: "GAS CONVERSION"); this operation must be carried out by a qualified technician in compliance to the regulations in force;
- the gas supply cock is open;
- there are no gas leaks;
- the external mains supply switch is on;
- the boiler system's safety valve is not blocked and that it is connected to the sewage system;
- the condensate drain siphon has been filled with water and that it is connected to the sewage system;



DANGER!

Before firing the appliance fill up the siphon through the filling hole and check the correct drainage of the condensate.

If the appliance is used with the condensate drain siphon empty this could cause poisoning caused by the leakage of the flue gasses.

- there are no water leaks;
- all the necessary ventilation conditions and minimum clearance distances are guaranteed for subsequent servicing in case the boiler is sited in a cupboard compartment.

Lighting and shutting down procedures

For lighting and shutting down the boiler refer to the "USER'S INSTRUCTIONS GUIDE".

Information to be passed on to the user

The user must be instructed on the use and operation of his boiler and in particular detail:

- Hand over to the end user the booklet: "USER'S INSTRUCTIONS GUIDE", as well as all the other literature relative to the appliance and placed in the envelope contained in the packaging. **The user must retain this literature for any future reference.**
- Inform the user of the importance of the air vents and of the flue outlet system, stressing the fact that absolutely no alteration can be made.
- Inform the user regarding the control of the system's water pressure and how to restore it to the correct value.
- Explain and demonstrate to the user the correct function and adjustment of the temperature, thermostats and radiators for the economic use of the system.
- Remind the user that in order to comply to the regulations in force the boiler has to be inspected and serviced regularly as indicated by the manufacturer.
- If the appliance is sold or transferred to another owner or if the present user moves home and leaves the appliance installed, ensure yourself that the manual always follows the appliance so that it can be consulted by the new owner and/or installer.

3.19 - BURNER PRESSURE ADJUSTMENT



WARNING!

All the instructions indicated below are for the exclusive use of qualified UNICAL service technicians or installers.




All the boilers leave the factory already calibrated and tested. If it is necessary to change the calibration due to gas conversion or adaptation to the mains supply system, the gas valve must be re-calibrated.


Warning: during this operation do not request any domestic hot water.

A) MAX OUTPUT ADJUSTMENT

- Remove the cap and connect a suitable CO₂ gas analyser to the sampling point in the flue inlet/outlet terminal.





Set the boiler in "calibration" mode by rotating the HEATING knob "B" to its MAX setting and then press the RESET push button for 3 s (symbol wrench = steady ON and symbol radiator = steady ON).



3 sec.




- Check that the CO₂ values are within the values indicated in the table "Burner pressures".
- If necessary correct the value by turning the adjustment screw "A" in a CLOCKWISE direction to decrease the value and in an ANTICLOCKWISE direction in order to increase it.





MAXIMUM OUTPUT
ADJUSTMENT SCREWS

B) MIN OUTPUT ADJUSTMENT

Rotate the HEATING knob "B" in the zone between the sun and the MIN temperature: the boiler operates at minimum output (symbol wrench = steady ON and symbol radiator = flashing).



- Check that the CO₂ values are within the values indicated in the table "Burner pressures".
- If necessary correct the value by turning the adjustment screw "B" in a CLOCKWISE direction to increase the value and in an ANTICLOCKWISE direction in order to decrease it.



MINIMUM OUTPUT
ADJUSTMENT SCREWS



Note:

Do not force the adjusting screws over the limits (when noticing a different resistance).



The chimney sweeper mode remains active for 15 minutes. To disable the **chimney sweeper mode** before this time has run out, press the Reset "G" key for at least 3 seconds.

Instruction for the installer

C) COMPLETION OF THE BASIC ADJUSTMENTS

- Check the CO₂ values at the minimum and maximum output.
- If necessary make the required adjustments.



To ensure correct boiler operation the CO₂ values have to be adjusted with extreme care respecting the values indicated in the table.




C

- Close the sampling test point in the flue inlet/outlet terminal with the appropriate cap C.

In case of gas valve replacement or difficult ignition:

Screw down completely the maximum adjustment screw "A" in a clockwise direction, then slacken for 7 turns.

Check the boiler ignition; if the boiler goes into lockout slacken the screw "A" again of one turn, then retry ignition. If the boiler goes into lockout again, carry out the above indicated operations until the boiler is fired. At this point carry out the burner adjustment as previously indicated.



INJECTORS – PRESSURES

Check the CO₂ levels often, especially at low output

Gas type	Supply pressure (mbar)	Collector Diaphragm (Ø and n. holes)	CO ₂ levels (%)		Fan speed (rpm)		Mixer injector (Ø mm)	Flue outlet diaphragm (Ø mm)	Min gas consumption	Max gas consumption	Start-up firing rate %
			min	max	min	max					

ALKON 09 R 18 - C 18

Nat. gas (G20)	20	-	9,5	9,5	1800	5300	5,6	-	0,47 m³/h	1,90 m³/h	70
LPG (G31)	37	8,8 x 8	11,0	11,0	1800	5300	5,6	-	0,34 kg/h	1,40 kg/h	70

ALKON 09 R 24 - C 24

Nat. gas (G20)	20	-	9,5	9,5	1800	6800	5,6	-	0,47 m³/h	2,52 m³/h	50
LPG (G31)	37	8,8 x 8	11,0	11,0	1800	6800	5,6	-	0,34 kg/h	1,85 kg/h	50

In some geographical zones particular gas distributing conditions can occur, such as a different mixing of components: This will require an optimization of the boiler calibration, which can be different than the one factory made.

INCONVENIENTS	SOLUTIONS
Noisy flame at cold start	Act on the parameter IG via the REGOLAFACILE, section "TECHNICAL MENU", parameters TSP, increasing the value by about 5-10% maximum.
Noisy flame in steady state	Increase the CO ₂ value by 0.2 to 0.4% maximum.
Noisy flame in modulation	Min CO ₂ >= 9% LPG: Max CO ₂ = 11% Min CO ₂ >= 10.2%



These adjustments can be performed only by Service Centres authorized by UNICAL.

UNICAL is not responsible for any damages caused to persons, animals and goods deriving from this infringement

3.20 - VARIATION OF OUTPUT RANGE

It is possible to adjust the maximum input by reducing the fan speed.


With the "Regolafacile" parameter n°4 (HP):

rpm x 100 ex. 70 = 7000 rpm


For example: with the parameter HP settled on 82, the correspondent maximum input will be of 16 kW (Alkon 09 18kW).

For example: with the parameter HP settled on 80, the correspondent maximum input will be of 20 kW (Alkon 09 24kW).

ALKON 09 R/C 18



ALKON 09 R/C 24



4

INSPECTION AND SERVICING SCHEDULE

To ensure the continued safe and efficient operation of the boiler it is highly recommended that it is checked at regular intervals and serviced when necessary, and that only original spare parts are used. Regular attention will prolong the life of the boiler.

If the boiler is not checked and serviced regularly it could cause material and personal damages.

For this reason UNICAL recommends that a servicing contract should be made with our authorized After Sales Service Assistance Centre.

The boiler must have regular maintenance and cleaning in order to ensure reliable and efficient operation. Regular attention will prolong the life of the boiler.

The frequency of servicing will be determined by the service engineer and will depend on the appliance's state of condition.

These adjustments can be performed only by Service Centres authorized by UNICAL.

UNICAL is not responsible for any damages caused to persons, animals and goods deriving from this infringement.

For a better operation of your appliance follow the suggested servicing as shown on page 43

INSTRUCTIONS FOR INSPECTION AND SERVICING

To ensure a long life to all your boiler components and in order not to alter the conditions of the approved product, only original UNICAL spare parts must be used.

Before servicing always carry out the following steps:

- Disconnect the mains electricity supply.
- Separate the appliance from the electrical supply by means of a separating device with an opening contact of at least 3 mm (for example safety devices or power switches) and ensure yourself that it cannot be accidentally reinserted.
- Close the on-off valve fitted upstream of the boiler.
- If necessary, and in function of the type of work to be carried out, close any on-off valves fitted on the CH flow and return pipes, as well as the cold water inlet valve.
- Remove the appliance's front panel.

After having carried out all the necessary maintenance work always follow these steps:

- Open the CH flow and return valves as well as the cold inlet valve (if previously closed),
- Purge and, if necessary, proceed with restoring the heating system's pressure until a pressure of 0,8/1 bar is reached.
- Open the on-off gas cock.
- Reconnect the appliance to the electrical supply and switch on the mains electrical supply.
- Test for gas soundness, on the gas side and on the water side.
- Replace the appliance's front panel.

TABLE OF RESISTANCE VALUES AS A FUNCTION OF THE HEATING SENSOR (SR) AND DHW (SS) TEMPERATURE SENSORS

T°C	0	1	2	3	4	5	6	7	8	9
0	32755	31137	29607	28161	26795	25502	24278	23121	22025	20987
10	20003	19072	18189	17351	16557	15803	15088	14410	13765	13153
20	12571	12019	11493	10994	10519	10067	9636	9227	8837	8466
30	8112	7775	7454	7147	6855	6577	6311	6057	5815	5584
40	5363	5152	4951	4758	4574	4398	4230	4069	3915	3768
50	3627	3491	3362	3238	3119	3006	2897	2792	2692	2596
60	2504	2415	2330	2249	2171	2096	2023	1954	1888	1824
70	1762	1703	1646	1592	1539	1488	1440	1393	1348	1304
80	1263	1222	1183	1146	1110	1075	1042	1010	979	949
90	920	892	865	839	814	790	766	744	722	701

Relationship between the temperature (°C) and the nominal resistance (Ohm) of the CH sensor and the DHW sensors.

**Example: At 25°C, the nominal resistance is 10067 Ohm
At 90°C, the nominal resistance is 920 Ohm**

Inspections and servicing schedule

Recommended servicing operations	Check annually	Check every 2 years
Examine all water seal components for soundness	●	
Test for gas soundness		●
Check the water and gas safety devices	●	
Clean the combustion circuit heat exchanger/body	●	
Clean the burner and check the ignition efficiency	●	
Clean the fan	●	
Check efficiency of fan's operation		●
Check the gas flow rate and eventual gas adjustment	●	
Check the flue outlet system	●	
Check the hydraulic system		●
Combustion analysis		●
Clean the DHW heat exchanger (only on the "C" model)		●
Control the efficiency of the electrical and electronic components		●
Clean the condensate drain siphon and check that it is discharging correctly	●	



WARNING!


If, during the routine servicing, the burner appears slightly curved, inflect the burner by pushing from the outside of the curve and refit it.




WARNING!

It is fundamental to correctly position the burner in its dedicated seat.




Burner seat



Burner



Sealing gasket




DANGER!

If, during inspection visits and/or servicing of the appliance, the heat exchanger/boiler body has to be dismantled, the sealing gasket **MUST** be replaced each time.

When reassembling the distributor, ensure that the nuts are re-screwed in sequence, using a suitable dynamometric spanner calibrated to 8 Nm (0,8 kgm).

Example of crossed tightening sequence



5

FAULT CODES

The symbol  flashes on the display when the boiler detects a fault.

1) In case of a fault which does not causes the stop of boiler operation, to show the error code it is necessary to press the reset push button. If the boiler is in stand-by the error code appears in the display also without pressing the reset push button.



2) In case of an error code which causes the stop of boiler operation, the error code is shown directly on the display in flashing mode.

Each error is characterized by a priority level: if two errors are detected at the same time, the error code with higher priority is shown. Here below the list of the known errors.



Outer temperature sensor (priority 0)

Description:

Outer temperature sensor interrupted

Possible solutions:

Inspect the harness; if necessary replace the outer sensor.




Heating return temperature sensor (priority 1)

Description:

Return temperature sensor interrupted

Possible solutions:

Inspect the harness; if necessary replace the return temperature sensor.



Working parameters (priority 2)

Description:

Working parameters corrupted

Possible solutions:

Re-introduce the correct working parameters.



Insufficient circulation (priority 3)

Description:

Insufficient circulation in the primary circuit

Possible solutions:

Inspect the operation of the pump and its speed adjustment



Mistension supply to the burner (priority 4)

Description:

It depends on the electrical supply (Frequency and Voltage out of the standard limits)

Possible solutions:

Wait for the values entering within the limits




Heating flow and return temperature sensors (priority 5)

Description:

*Water circulation through primary circuit **very** weak*

Possible solutions:

Inspect the operation of the pump and its speed setting; remove possible obstructions of the C.H. system; clean the possible fouled D.H.W. heat exchanger.



Heating flow and return temperature sensors (priority 6)

Description:

Heating flow and return temperature sensors inverted

Possible solutions:

Inspect the harness




Fan (priority 7)

Description:

Alteration of the fan speed

Possible solutions:

Inspect the operation of the fan and its harness.




High temperature (priority 8)

Description:

Boiler temperature too high

Possible solutions:

Ascertain the good operation of the pump and, eventually, clean the heat exchanger




Low pressure (priority 9)

Description: *Insufficient water pressure and, consequently, intervention of the minimum water pressure switch*

Possible solutions:

Restore the water pressure through the filling valve and check for possible water leaks.




Freezing (priority 10)

Description:

The freezing of the heat exchanger has been detected. When the flow temperature sensor detects a temperature below 2°C the burner ignition is inhibited till the sensor detects a temperature higher than 5°C.

Possible solutions:

Cut the electrical supply to the boiler, close the gas cock, defreeze, carefully, the heat exchanger.




Safety thermostat (priority 11)

Description: *Intervention of the safety thermostat.*

Possible solutions:

Press the reset push button on the panel board and ascertain that the thermostat and/or its harness is not interrupted..




D.H.W. temperature sensor (priority 12)

Description:

Intervention of the D.H.W. temperature sensor (if applicable)

Possible solutions:

Check the sensor for good operation (see table Resistance/Temperature) and/or its harness.




C.H. flow temperature sensor (priority 13)

Description: *Intervention of the C.H. flow temperature sensor*

Possible solutions:

Check the sensor for good operation (see table Resistance/Temperature) and/or its harness.



Factory parameters (FA) (priority 14)

Description: *Corruption of Factory parameters (FA)*


Possible solutions: *Press the reset button on panel board: if the inconvenient is not solved replace the PCB*



Lockout (priority 15)

Description: *Lack of gas or burner ignition*


Possible solutions: *Check the gas supply and/or the ignition electrode/ionization.*



Parasitic flame (priority 16)

Description: *Flame detected during ignition phase*


Possible solutions: *Inspect the harness of the combined ignition/ionization electrode and remove possible oxidation from electrode; if the problem is not solved replace the electrode.*



Parasitic flame (priority 17)

Description: *Flame detected after the extinction of the burner*

Possible solutions: *Inspect the harness and check for possible internal leak of the gas valve.*



Flame control (priority 18)

Description: *Damaged flame control*

Possible solutions: *Replace PCB*



(Directives 2009/142/CE « Appareils à gaz » et 92/42/CE « Rendement des chaudières »)
(« Gas appliances » 2009/142/EC and 92/42/EC « Boilers efficiency » Directives)

Numéro : 1312BT5288 (rév. 2)

CERTIGAZ, après examen et vérifications, certifie que l'appareil :

CERTIGAZ, after examination and verifications, certifies that the appliance :

- **Fabriqué par :**
Manufactured by : **UNICAL AG SpA**
Via Roma, 123
I-46033 CASTEL D'ARIO (MN)
- **Marque commerciale et modèle(s) :**
Trade mark and model(s) :

UNICAL

 - ALKON 09 C 24 – ALKON 09 R 24
 - ALKON 09 C 18 – ALKON 09 R 18
 - ALKON C 24 HE – ALKON R 24 HE
 - ALKON C 18 HE – ALKON R 18 HE
 - ALKON 09 R 12
- **Genre de l'appareil :**
Kind of the appliance : **CHAUDIERE CONDENSATION**
CONDENSING BOILER
(Types : B23, C13, C33, C43, C53, C63, C83, C13x, C33x, C43x, C63x, C83x)
- **Désignation du type :**
Type designation : **ALKON 09**

Pays de destination <i>Destination countries</i>	Pressions (mbar) <i>Pressures (mbar)</i>	Catégories <i>Categories</i>
FR	20/25 ; 37	II2Esi3P
ES-GB-IE-IT-PT-GR-SE-NO	20 ; 37	II2H3P
DE	20 ; 50	II2ELL3P
HU	25 ; 50	II2HS3P
AT-CH-TR-HR-CZ-SK-SI	20 ; 50	II2H3P
LV-EE-LT	20	I2E
BE	20/25	I2E(S)
BE	37	I3P
NL	25 ; 50	II2L3P
BG-CN-RU-RO-YU	20	I2H
PL	20 ; 13 ; 37	II2ELs3P
LU	20 ; 50	II2E3P
BA	25	I2H

est conforme aux exigences essentielles des directives « Appareils à gaz » 2009/142/CE et « Rendement des chaudières » 92/42/CE.

is in conformity with essential requirements of 2009/142/EC « Gas appliances » and 92/42/EC « Boiler efficiency » directives.

CERTIGAZ
Le Directeur Général


Kris DE WIT

Paris le : 22 mars 2010

Rév. 2 : 1312BT5288 du 2008/12/16

PERFORMANCES ENERGETIQUES

ENERGY PERFORMANCE

Directive 92/42/CE « Rendement des chaudières »
92/42/EC « Boilers efficiency » Directive

Annexe au certificat**Numéro : 1312BT5288** (rév. 2)

- **Fabricant :** **UNICAL AG SpA**
Manufacturer : **Via Roma, 123**
I-46033 CASTEL D'ARIO (MN)
- **Type de chaudière :** **CHAUDIERE CONDENSATION**
Type of boiler : **CONDENSING BOILER**
(Types : B23P, C13, C33, C43, C53, C63, C83, C13x, C33x, C43x, C63x, C83x)

Marque commerciale et Modèle(s) <i>Trade mark and Model(s)</i>	Label <i>Label</i>
UNICAL ➤ ALKON 09 C 24 – ALKON 09 R 24 ➤ ALKON 09 C 18 – ALKON 09 R 18 ➤ ALKON C 24 HE – ALKON R 24 HE ➤ ALKON C 18 HE – ALKON R 18 HE ➤ ALKON 09 R 12	4 ★

**Paris le : 22 mars 2010**

Rév. 2 : 1312BT5288 du 2008/12/16

UnicalAG S.P.A.

46033 casteldario - mantova - italia - tel. +39 0376 57001 (r.a.) - fax +39 0376 660556
www.unical.ag - info@unical-ag.com

The Unical declines every responsibility for the possible inaccuracies if owed to errors of transcript or press. Also reserves the right to bring those changes that it will hold necessary to its own products or profits, without jeopardizing its essential characteristics.

