



NOMENCLATURE

- | | |
|--|--|
| 1 - Flame nozzle OM29260 | 29 - Pressurization ring control rod fixture SCREW M8 |
| 2 - Flame nozzle extension OM29250 | 30 - Flame nozzle extension retaining screws 02270880 (3) |
| 3 - Insulation gasket | 31 - Air intake valves |
| 4 - Boiler coupling plate | 32 - Air conveyor |
| 5 - Auger cover retaining screw | 33 - Gas/oil switch |
| 6 - Auger cover | 35 - Start/stop switch |
| 7 - Flame control light | 36 - Air pressure switch |
| 9 - Flame control device | 37 - Oil pressure outlet connector |
| 10 - Lock reset luminous button | 38 - Gas pressure switch 04037250 |
| 11 - Fan motor overload cutout | 39 - Pilot electrovalve |
| 12 - Electric panel cover | 40 - Main electrovalve |
| 14 - Ground screw | 41 - Ignition transformer |
| 15 - Gas feed pipe retaining screws | 42 - Gas feed pipe |
| 16 - Serial number plate | 43 - Pump pressure adjustment screw |
| 17 - O-ring | 44 - Fuel pump |
| 18 - Pressurization ring OM29240 | 45 - Vacuometer attachment |
| NB. 3 19 - Flame nozzle retaining screws 02272620 | 46 - Flexible hoses |
| 20 - Baffle disc OM29310 | 47 - Pressure gauge attachment |
| 21 - Oil first stage nozzle 04030860 | 48 - Oil feed pipe retaining screw |
| 22 - Ignition electrodes OM29280 | 49 - Photocell holder |
| 23 - Ignition electrode cables | 50 - Photocell |
| 24 - Fan electric motor | 52 - Oil 2nd stage nozzle 04030860 |
| 25 - Oil 1st stage electrovalve | 53 - O-ring |
| 26 - Oil 2nd stage electrovalve | 54 - Electrode support retaining screws |
| 27 - Fuel pump motor | 55 - MIN/MAX switch |
| 28 - Air adjustment servocontrol | |




Fig-18




Fig-19




Fig-20